

## Portable charger

Comes pre-charged

- Charge your cellphone, AA batteries, iPod and digital devices
- Instant power wherever you are
- Flashlight function
- Recharge the included AA batteries to use in other devices too



### Pack contents:

1. Powerchimp
2. Carry case
3. DC3.5 x 1.1 charging cable
4. Retractable USB charging cable
5. 2 x AA 1800mAh rechargeable batteries
6. iPod tip (colour may vary)
7. Samsung E300 tip
8. Motorola V66 tip
9. Mini USB
10. Sony Ericsson tip
11. Female USB
12. LG Chocolate tip
13. DC4.0 PSP tip
14. Mini Nokia tip

Other tips are available at [www.powertraveller.com](http://www.powertraveller.com)



1. Battery compartment for 2x AA batteries in underside of powerchimp
2. Removable battery compartment cover
3. Power socket cover attached with flexible strap



1. Powerchimp being charged via USB
2. LED in red charge input mode
3. Retractable USB charging cable



Powerchimp is available in four colours: grey, blue, pink and yellow



## How to use your powerchimp:



1. Tough outer shell
2. Soft function button
3. LED
4. Charging cable
5. Input/output socket with soft removable cover
6. Flashlight

### To charge your cellphone, iPod and digital devices:

- To switch your powerchimp on, depress the black button (2) twice until LED (3) flashes green
- Select the right tip for your device. If the tip you need is not included in this pack, visit [www.powertraveller.com](http://www.powertraveller.com)
- Attach tip to charging cable (4)
- Connect charging cable to your cellphone or device through its standard charging socket
- Undo soft cover from top of powerchimp input socket (5) and connect cable
- LED green flashing light indicates charging
- Powerchimp turns itself off 2 minutes after fully charged
- LED flashing red light means unit needs charging

### Recharge your rechargeable batteries:

Charge by connecting powerchimp to the USB port of your computer/laptop

LED solid red light indicates charging; if flashing red, it is not charging and will turn green when fully charged

### Flashlight:

To activate press black button (2) three times.

### Recharge your powerchimps:

- Flashing red light means unit needs recharging
- Fully charge your powerchimp from the USB on your laptop in 5 hours
- Plug tip of retractable USB charging cable into USB port of your laptop or other USB socket
- Plug other tip into powerchimp input socket
- LED is red when charging; LED turns green when fully charged
- May also be charged via mains and solar power



### Use powerchimp to power up these devices:

- Cellphones - approx. 48 hours standby time and 4 hours talk time
- iPod - approx 20 hours; 4 hours if watching video
- AA rechargeable batteries - charge in approx. 2 hours
- MP3/MP4s - approx. 3 hours
- PSPs - approx. 2.5 hours
- PDAs - approx. 24 hours

Note: actual times will vary according to charge in the batteries and quality of batteries used.


Extra charging accessories featured here can be purchased from [www.powertraveller.com](http://www.powertraveller.com)



Worldwide Mini/UK adaptor, Solemonkey, AA rechargeable batteries

For customer support, please email: [support@powertraveller.com](mailto:support@powertraveller.com)

For additional tips not included in this pack, and to see the full range of Powertraveller devices and accessories visit [www.powertraveller.com](http://www.powertraveller.com)



MADE IN CHINA

Powertraveller Ltd  
8 Delta Park, Wilson Road, Alton  
Hampshire, GU34 2RQ, UK

Tel: +44 (0) 1420 542980

